



**Future Technology Devices
International Ltd.**

**AN232B-03 Optimizing D2XX Data
Throughput**

Table of Contents

Part I D2XX Applications - Optimizing Data Throughput Over USB	2
1 Introduction	2
2 Transfer Sizes	3
3 Driver Operation	4
4 Optimizing Performance	5
Part II Revision History, Disclaimer, and Contact Information	6
1 Document Revision History	6
2 Disclaimer	7
3 Contact Information	8
Index	9

1 D2XX Applications - Optimizing Data Throughput Over USB

1.1 Introduction

This application note provides guidelines for achieving optimal performance over USB from D2XX applications.

1.2 Transfer Sizes

The maximum transfer size over USB is setup once and for all when a device is initialized. An application can change the current USB transfer size to a value not exceeding the maximum USB transfer size. The best transfer size for an application depends on its type. For example, an application that handles streaming data will run more efficiently with a large transfer size, whereas a smaller transfer size may be more suited to an application that handles small amounts of data.

1.3 Driver Operation

In the D2XX device driver, the maximum USB transfer size is set at 64Kbytes. This is necessary in order to support USB2.0 controllers: on USB2.0, we have found that transfer sizes greater than 64K fail catastrophically.

Current USB transfer size can be changed using the function *FT_SetUSBParameters*. The change comes into effect immediately, and any data that was held in the driver at the time of the change is lost.

Note that, currently, *FT_SetUSBParameters* supports transfer size changes for the IN endpoint only, and the remainder of this note is restricted to consideration of read requests.

When a device is opened, the driver allocates two buffers: a USB transfer buffer of maximum USB transfer size bytes and a read buffer whose size is based on, but not the same as, the maximum USB transfer size. The current USB transfer size is set by default to 4Kbytes, but an application may setup the current USB transfer size anytime after a device has been opened. The driver performs USB requests of any size up to the current USB transfer size, then copies the data to the read buffer. The actual USB request size is determined by the space that is currently available in the read buffer. If the read buffer becomes full (i.e. there is not enough space in the read buffer to hold data returned from a USB request), the driver will stop issuing USB requests until space becomes available.

Data is removed from the read buffer when the application performs a read request. So the rate at which the application issues read requests has a direct bearing on the driver's ability to keep issuing USB requests. USB requests will continue to be issued as long as the application performs enough read requests to ensure that the read buffer does not become full.

1.4 Optimizing Performance

The question of how to setup an application for optimized data throughput is complicated by the format of the data that is transferred over USB. Data is transferred over USB in a series of 64 byte packets. Each packets contains two bytes that are reserved by FTDI and 62 bytes of actual data. So a 4Kbyte USB transaction contains 3968 bytes of actual data, and a 64Kbyte transaction contains 63488 bytes. In general, an x byte USB transaction yields $x - ((x/64)*2)$ bytes of actual data.

Optimized throughput occurs when the maximum amount of data is transferred in the least possible number of USB transactions. The necessary condition is that the application's request size must be matched to the current USB request size. More precisely, optimal throughput is achieved when the application request size is a multiple of the number of actual data bytes contained in the current USB transfer size. For example, using a current USB transfer size of 4Kbytes, optimal throughput is achieved with application request sizes that are multiples of 3968 bytes.

Maximum throughput is achieved using a current USB transfer size of 64K bytes, and application requests that are multiples of 63448 bytes.

2 Revision History, Disclaimer, and Contact Information

2.1 Document Revision History

Version	Release Date	Comments
1.0	March 2004	Initial release.
1.1	February 2006	Format and contact information updated.

2.2 Disclaimer

Copyright © 2006 Future Technology Devices International Ltd.

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder.

This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. Future Technology Devices International Ltd. will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected.

This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury.

This document provides preliminary information that may be subject to change without notice.

2.3 Contact Information

Head Office - Glasgow, UK

Future Technology Devices International Limited
373 Scotland Street
Glasgow
G5 8QB
United Kingdom
Tel: +44 (0) 141 429 2777
Fax: +44 (0) 141 429 2758

E-Mail (Sales): sales1@ftdichip.com
E-Mail (Support): support2@ftdichip.com
E-Mail (General Enquiries): admin1@ftdichip.com
Web Site URL: <http://www.ftdichip.com>
Web Shop URL: <http://apple.clickandbuild.com/cnb/shop/ftdichip>

Branch Office - Taiwan

Future Technology Devices International Limited (Taiwan)
4F, No 16-1, Sec. 6 Mincyuan East Road
Neihu District
Taipei 114
Taiwan
ROC
Tel: +886 2 8791 3570
Fax: +886 2 8791 3576

E-Mail (Sales): tw.sales1@ftdichip.com
E-Mail (Support): tw.support1@ftdichip.com
E-Mail (General Enquiries): tw.admin1@ftdichip.com
Web Site URL: <http://www.ftdichip.com>

Branch Office - Hillsboro, Oregon, USA

Future Technology Devices International Limited (USA)
5285 NE Elam Young Parkway
Suite B800
Hillsboro, OR 97124-6499
USA
Tel: +1 (503) 547-0988
Fax: +1 (503) 547-0987

E-Mail (Sales): us.sales@ftdichip.com
E-Mail (Support): support2@ftdichip.com
E-Mail (General Enquiries): admin1@ftdichip.com
Web Site URL: <http://www.ftdichip.com>

Agents and Sales Representatives

Please visit the [Sales Network](#) page of the [FTDI Web site](#) for the contact details of our distributor(s) in your country.

Index

- B -

Buffers 4

- D -

D2XX 2, 4

Data Format 5

- F -

FT_SetUSBParameters 4

- I -

IN Endpoint 4

- M -

Maximum Transfer Size 3

Maximum USB Transfer Size 4

- P -

Packets 5

- R -

Read Buffer 4

Read Requests 4

- U -

USB 2.0 Controllers 4

USB Request 4

USB Request Size 5

USB Transactions 5

USB transfer Buffer 4

USB Transfer Size 3, 4